EN 12594: Preparation of bituminous samples

Place the container of bitumen (< 1 l) with the lid loose in the oven for max 120 minutes, at less than 100°C above $T_{R\&B}$

Remove the bitumen from the oven and stir the melted sample to ensure homogenity and prevent air bubbles from forming

If necessary, reinsert the bitumen in the oven for 5 minutes to ensure all air bubbles have been removed

Pour the liquefied homogenized blend in the appropriate molds or cans

Store the molds or cans appropriately before testing



- 1) Always contact the permanence in case of doubt.
- 2) Personal Protection Equipment







) Risks

Melting time
according to
quantity of sample:
1-2 L → < 180 min
2-3 L → < 210 min
3-5 L → = 240 min
> 5 L → overnight



Contact	
Lab manager	Johan Blom
Device manager	Georgios Pipintakos

